






AFI CAMPUS EVACUATION MAP

SONY DIGITAL ARTS CENTER



LEGEND

-  EMERGENCY PHONE
-  EVACUATION ROUTE
-  FIRE ALARM
-  FIRE EXTINGUISHER



TO CONTACT SECURITY IN AN EMERGENCY
 USE THE EMERGENCY PHONE ON THIS FLOOR OR DIAL 323.467.6456 FOR ASSISTANCE